



seperat 12V supply
OR +12V from computer
NOT 12V from radio

RADIO1/2

- 1: soundcard output
- 2: GND
- 3: Isoundcard input
- 4: COMport pin 4

- 1: radio audio out RX
- 2: GND
- 3: radio TX audio input
- 4: PTT put to GND at TX



Title OZ1IEZ SSTV INTERFACE		
Size A4	Document Number sstv_dual.dsn	Rev a
Date Sunday, March 02, 2008	Sheet 1	of 1